

1250 ✓ DOMINATOR

Pressluftgewehr | Air rifle

Carabine à air comprimé | Carabina de aire comprimido



BEDIENUNGSANLEITUNG OPERATION INSTRUCTIONS MODE D'EMPLOI MANUAL DE INSTRUCCIONES

1.1 | 1250 DOMINATOR

GB

CAUTION: This symbol indicates the presence of safety directions in the operating instructions. When you see this symbol, pay attention and read the corresponding section carefully. For your own safety and that of others, read all the operating instructions provided. Do not load the diablo pellets until you are ready to shoot. If you have loaded the rifle and decide not to shoot, unload it as described below. To guarantee maximum safety, keep the rifle unloaded with the safety on. Accidents always happen unexpectedly and may cause injuries and even death. Pay special attention when you are shooting


The chapter "Point and shoot safely" of these instructions deals with the rules for shooting safely. READ THIS CHAPTER. Follow these rules and make sure that all those who handle the weapon are familiarized with its handling and the safety rules. Also read the chapter "Safe weapon handling" to avoid accidents.

Your new air rifle must be used with care and respect. Always remember that the operator of a weapon is the greatest safety measure. All of the safety devices are mechanical and it is only the person shooting who sets or releases the safety. DO NOT PLACE FULL TRUST IN THE MECHANICAL SAFETIES: Be wise and avoid situations that might cause an accident.

Each weapon handles differently. For this reason, never fire a weapon until you are familiar with it. Read the following usage instructions and become familiar with the handling of the weapon WITHOUT LOADING IT (aiming at a safe target) until you feel comfortable using the weapon correctly and safely.

CAUTION: Never leave the weapon loaded. Always store the weapon unloaded. Activate the safety (position S) and carefully make sure that there is no pellet in the barrel or diablo pellets in the drum. Keep the weapon out of the reach of children and those who are unfamiliar with its use. Store diabolos and compressed air cylinders in a separate location and keep them out of reach of non-familiarized users or unauthorized persons.

1.2 | THE PARTS OF YOUR NEW AIR RIFLE



- | | | | |
|---|---------------|----|-------------------------|
| 1 | Muzzle | 7 | Trigger |
| 2 | Front sight | 8 | Stock end pad |
| 3 | Sight | 9 | Cheek piece |
| 4 | Drum magazine | 10 | Bolt lever |
| 5 | Safety | 11 | Compressed air cylinder |
| 6 | Stock | | |

If you memorize the names of the different parts of your new rifle, it will help you to more easily understand the usage instructions. Read this manual carefully to gain full enjoyment from your new weapon.

| 22

2.1 | HANDLING THE SAFETY

After each shot, the weapon will automatically have the safety in place.

WARNING: Get used to leaving the weapon uncocked and the safety activated until it is time to shoot.

- To set the safety manually, pull the safety back, as shown in illustration 1.a, until it is in position (the red mark is hidden).
- Handle the weapon only with the safety in place. Always point the barrel of the weapon in a safe direction.
- The rifle is fitted with a double safety system. To deactivate it, you must: 1. press the fixing lever down and 2. push the safety button forward (illustration 1.b)
The red mark is visible and the weapon is ready for shooting (illustration 1.c).



Illustration 1.a safety activated




Illustration 1.b



Illustration 1.c ready for shooting

2.2 | HANDLING THE COMPRESSED AIR CYLINDER

Note: To guarantee good operation, make sure you use only Umarex accessories.

Insert the new compressed air cylinder into the shaft first (Fig. 2.a) and screw it tight. The gun is now under pressure. To test whether the cylinder has been screwed in correctly, make sure the gun is not loaded and shoot in a safe direction. If the gun doesn't fire, check the items in Section 4 "Problems".

CAUTION: The gun remains under pressure even after removal of the compressed air cylinder.

CAUTION: To release all the pressure, unscrew the compressed air cylinder, remove the drum magazine and shoot in a safe direction until the gun can no longer fire.



Fig. 2.a



Fig. 2.b

| 24

2.3 | LOADING THE DRUM MAGAZINE

- Activate the safety (see chap. 2.1 "Handling the safety").
- Pull back the bolt lever of the lock and the retainer of the drum (see the sequence in illustration 4.a).
- Remove the drum from the weapon (illustration 4.b).
- Load the drum magazine by inserting diabolo pellets in its holes (illustration 3.a).
The diabolo pellets are held in place by an o-ring that traps them.
- Your new weapon has been tested for faults with all the diabolo pellets described in the accessories section. Diabolo pellets with a maximum total length of 10 mm may be loaded.

Filling procedure

The compressed air cylinder can be refilled at any time, even if it is not yet empty. When filling, observe the provisions of the TRG (technical regulations relating to pressurized gas). The maximum permissible filling pressure of 300 bars must not be exceeded under any circumstances. Observe applicable national statutory regulations for refilling. Cylinders which are leaky or otherwise unsafe must not be refilled. Empty them in a safe manner. Screw the adapter onto the refill cylinder and tighten it. Then screw the compressed air cylinder onto the adapter and tighten it securely. Open the cylinder valve for approx. 5 s and then close it. Remove the cylinder and screw it back onto the gun. Compressed air cylinders must never be used or stored above maximum pressure.

WARNING: Never try to use force when inserting a compressed air cylinder.

WARNING: Do not store compressed air cylinders at temperatures above 50°C (122 °C).

CAUTION: When you pierce a compressed air cylinder, make sure the weapon has the safety activated and that the barrel is pointing in a safe direction.

CAUTION: The air used must comply with DIN 3188 (breathing air).

WARNING: Do not use steel pellets (the so-called BBs), darts or similar unsuitable ammunition.




Illustration 3.a

2.4 | LOADING THE RIFLE

- Activate the safety (see chap. 2.1 "Handling the safety").
- Pull back the bolt lever of the lock and the drum retainer (see the sequence in illustration 4.a).
- Place the drum in the weapon (illustration 4.b).
- Push the retainer of the drum.
- Push the lever of the lock forward and lower it.

WARNING: A diabolo pellet is automatically loaded in the barrel during the locking process.

WARNING: Do not put your hand in front of the barrel. Do not put your finger on the trigger.
Caution: Always point the barrel of the weapon in a safe direction. Do not point the weapon at people or animals.



Illustration 4.a




Illustration 4.b

2.5 | UNLOADING THE RIFLE

- Activate the safety as described (see chap. 2.1 "Handling the safety").
- Pull back the bolt lever and then the drum retainer (illustration 4.a) to be able to remove the drum.
- Remove the drum magazine (illustration 4.b).
- If there is a pellet in the barrel, remove it with a cleaning brush or proceed as described in chapter "Jams".
- Do not try to shoot a used diabolo pellet. It might damage the drum and the barrel.
- Remove the pellets from the drum magazine by pressing with a sharp object.
- Make sure the gun is completely unloaded.
- Put the empty drum back into the weapon.
- Push the bolt lever forward.

- Hold the weapon pointing in a safe direction.
- Release the safety and uncock by pulling the trigger and making a blank shot.

⚠ WARNING: When removing any Diabolo pellet from the barrel with a cleaning brush, place the rifle horizontally (see chapter "Jams"). Do not hold the weapon in a vertical position, as the pellet could fall into the mechanism and cause damage.

⚠ WARNING: Never use sharp metal objects to remove diabolo pellets from the drum magazine or the weapon. Any damage to the drum or the barrel could cause faulty operation.

2.6 | POINT AND SHOOT SAFELY

Make sure the weapon has the safety in place. Insert a compressed air cylinder and load the weapon as described. Make sure that your target is safe before shooting.

⚠ WARNING: Make sure that the weapon always points in a safe direction. Never point at people or animals. Always handle the weapon as if it were loaded and ready to fire.

⚠ WARNING: Due to this weapon's high shooting capacity, take particular care and caution in choosing a safe target. Only choose targets that cannot be pierced and that do not have a hard surface that can cause ricochets. Never shoot at liquid surfaces.

| 26

REPEATING (LOADING PROCESS)

After loading the weapon as described, make sure that the target, the pellet trap and the surrounding area are safe. In each repeating process, the drum moves forward one position. Activate the repeating by pulling the lock lever back and then pushing it forward once more to its original position (illustration 5.a). Disengage the safety as previously described. Your weapon is ready to fire now.






Illustration 5.a

FIRING CAPACITY

The capacity of the compressed air cylinder and thus the number of remaining shots can be read off the integrated pressure gauge. When the pressure falls to about 70 bars (7-joule and 16-joule variants) or 140 bars (28-joule and 40-joule variants), refill the cylinder (see chap. 2.2 "Handling the compressed air cylinder").



7-joule and 16-joule variants



28-joule and 40-joule variants

2.7 | ADJUSTING THE TRIGGER TRAVEL

Activate the safety.

Unload the weapon as described in point 2.5 "Unloading the rifle". Adjust your customized trigger travel by using a screwdriver to give a slight turn to the screw on the trigger (illustration 6.a).




Illustration 6.a

2.8 | JAMS

CAUTION: Shooting with insufficient pressure can cause a diabolo pellet to lodge in the barrel.

- Insert a new compressed air cylinder, remove the magazine, close the bolt lever and shoot without the drum magazine.
- The blocked pellet will fire.
- If this procedure fails to resolve the problem, remove the magazine and carefully press out the blocked pellet with a cleaning brush (cleaning rod).

⚠ WARNING: A jam is a dangerous situation.

⚠ WARNING: If the weapon fails to shoot, we must never assume that there is no ammunition left in the drum magazine.

⚠ WARNING: When removing any diabolo pellet from the barrel with a cleaning brush, place the rifle horizontally. Do not hold the weapon in a vertical position, as the pellet could fall into the mechanism and cause damage.




Illustration 7.a

| 28

2.9 | ADJUSTING THE SIGHT

Aim at a secure target:

Hold the weapon so that the rear sight is lined up with the front sight at the same time. The front sight should be exactly in the center of the notch of the rear sight. Next raise the gun so that the lower part of the bull's eye meets the front sight. The upper part of the rear sight, the upper part of the front sight and the lower part of the target should be in line (illustration 8.a, sight image). The point of impact can be adjusted as follows. The rifle is adjusted by the factory to shoot from a distance of 10 m.




Illustration 8.a too high too low right

To **adjust the elevation** of the sight, move the sight by slightly loosening the screw (illustration 8.b).

With excessively high shots:
With excessively low shots:

Move the sight back.
Move the sight forward.

Then retighten the screw.




Illustration 8.b




Illustration 8.c

To **adjust the windage** of the sight, it is necessary to move the front sight (Illustration 8.c):

If the gun shoots to the right:
If the gun shoots to the left:

Move the front sight to the right.
Move the front sight to the left.

2.10 | STORAGE

Always store the weapon with the ammunition removed and the safety on. Carefully check that there is no ammunition in the barrel and remove the diabolo pellets from the drum. Before storing it, also remove the compressed air cylinder.

Keep the weapon out of the reach of children and users not familiarized with its use. Store the weapon separately from the pellets and the compressed air cylinder.

⚠ WARNING: Never leave the weapon loaded.

3 | CARE

If you maintain and care for your weapon properly, you will be able to enjoy its use for many years.

Occasionally clean the exterior metal parts of the weapon. Use a soft cloth slightly dampened with special oil for weapons. To guarantee lasting operation, apply 2 or 3 drops of oil for weapons in the feeder and also in the weapon through the **empty** magazine (see illustration 9.a). Lubricate the rubber ring on the drum at regular intervals.

Never use fast cleaning pellets, as they can damage the weapon.

⚠ WARNING: Do not try to clean the weapon without applying the safety first, removing the compressed air cylinder and the drum, and making sure there is no pellet in the barrel



Illustration 9.a

| 30

4 | SAFETY INSTRUCTIONS

Problems	Possible causes						
	Safety activated	Cylinder is empty	Dirty barrel	Cylinder not correctly screwed on	High temperatures	Unsuitable ammunition	Diabolo pellets badly loaded
The weapon doesn't shoot		●	●		●	●	●
Faulty shooting direction	●	●		●		●	●
Low shooting speed		●	●		●	●	●

INSTRUCTIONS ON THE USE OF COMPRESSED AIR CYLINDERS

Sometimes the performance of an air gun is adversely affected by special factors. Among these conditions we find usage, maintenance and storage at certain temperatures higher or lower than normal outdoors (from 15 to 21 °C).

High temperatures can create a pressure in the compressed air cylinder and the gun itself which considerably exceeds the normal operating pressure. This excessive pressure might prevent firing and cause permanent damage to the weapon. Maximum temperature of storage or operation should never exceed 50 °C.

Compressed air cylinders which are leaky, damaged or more than 10 years old should be emptied in a safe manner and not used or filled again. Ten years after the manufacturing date, the compressed air cylinder must be tested at the owner's expense or replaced. The manufacturing date is recorded on the cylinder.

The air used must comply with DIN 3188 (breathing air). The maximum operating pressure of the compressed air cylinder (300 bars) must never be exceeded.

⚠ WARNING: Shooting with insufficient pressure can cause a diabolo pellet to lodge in the barrel. See the instructions on jams.

MODIFICATIONS IN THE WEAPON

⚠ WARNING: The different components of this weapon have been designed and manufactured to guarantee optimal function and performance at all times. Any modification in the design or adjustment in the performance may cause malfunction, and with it, the weapon could become unsafe. The warranty shall not be applicable if the rifle has been modified without authorization.

| 32

WARRANTY FOR WALTHER WEAPONS

WARNING: A weapon that malfunctions may be dangerous. Therefore, you should store it in a safe place so no one uses it before it is repaired. It is complicated to repair a weapon on your own. In addition, incorrect assembly can lead to dangerous malfunctions.

⚠ WARNING: Make sure the rifle is examined and repaired only by authorized, specialized personnel or by a weapons specialist.

WARRANTY FOR WALTHER WEAPONS

If the problem is a result of a manufacturing defect, Walther will repair or replace the weapon at no cost, as long as it is under the legal warranty which begins on the date of purchase. Give the weapon to an authorized distributor and describe the problem to him, providing the proper proof of purchase.

⚠ IMPORTANT: Before transporting your gun, make sure you have put on the safety and unloaded it.

Weapons also suffer from wear and tear. If they are used intensively, usage marks may appear which generally are not indicative of malfunctions. The drum magazines where the diabolo pellets are inserted suffer from special wear and tear, and therefore should be replaced when necessary (see chapter on special accessories).

SAFE WEAPON HANDLING

You should be familiar with the safe and proper handling of your weapon. Because your new weapon has a high shooting capacity, careful attention is advised. Regarding the basic rules to shoot safely, consider every contact you have with your weapon as part of its handling.

- Deactivate the weapon safety only when you are ready to shoot, and when you are done, activate it again immediately.
- Always handle the weapon as if it were loaded.
- Always apply the safety before loading, to ensure that no involuntary shots are made. Only put your finger on the trigger and pull it when you are going to shoot.
- Use only ammunition and compressed air cylinders designed for this weapon.
- Always keep the barrel of the rifle pointed in a safe direction.
- This weapon may only be shot on the owner's property or at shooting ranges allowed by the police, as long as the ammunition does not travel further than the shooting area. Bear in mind the maximum range of the pellet (approximately 300 m).
- Never transport the weapon when it is loaded. Only load it when you intend to shoot it.
- Never point the weapon at people or animals. Avoid shots where the ammunition could ricochet. Do not aim at hard, smooth objects or water. Pellets could ricochet.
- Before shooting, make sure the target and your surroundings are secure.
- Always confirm that the weapon is not loaded and that the safety is on when you carry it or give it to another person.
- Make sure the area toward which you are pointing the weapon is secure, including if you were to trip or the weapon were to fall.
- For safety reasons, wear protective glasses when you shoot.
- Always store the weapon unloaded, with the safety on. Keep the ammunition and the compressed air cylinder out of reach of unauthorized persons (those who have not been instructed on its use, children, persons under 18). Store ammunition separately.
- Give this weapon along with usage instructions only to those over 18, and make sure that they are as familiar as possible with its handling. In Germany a Weapons Possession Card (WBK) is required for versions above 7.5 joules muzzle energy.
- Any modification or repair of the weapon should be carried out by a specialized company or weapons store.
- Never leave the weapon loaded if it is out of your reach.
- Unload the weapon before giving it to someone else.

| 34

TECHNICAL DATA

	7.5 joules	16 joules	28 joules	40 joules
Caliber	4.5 mm (.177)			5.5 mm (0.22)
Magazine capacity	8 shots			
Length	40.94 in			
Weight	91.71 oz			
Muzzle speed (energy)	Up to 185 yd/s	Up to 275 yd/s	Up to 405 yd/s	Up to 320 yd/s
Barrel length	23.62 in			
Action	compressed air			
Safety	Automatic trigger safety			

CAUTION:

Carl Walther GmbH Sportwaffen air guns are made according to the regulations of the PTB (Physikalisch-Technischer Bundesanstalt) federal institute, German federal law, the regulations established in the CIP center and the broad experience in arms manufacture of Carl Walther GmbH Sportwaffen.

Therefore, we assume no liability if our products fail to meet the corresponding legal regulations when exported, or if the purchaser or owner might have legal difficulties or consequences in this respect.